

G-CEM LinkAce™ TECHNIQUE GUIDE



Prior to use, carefully read the instructions for use.

CEMENTATION TECHNIQUE for inlays, onlays, crowns, bridges



Clean, rinse and thoroughly dry the prepared tooth.



Prepare the restoration according to the manufacturer's instructions.



Extrude material into restoration. Seat immediately and maintain moderate pressure.

Maintain moderate pressure



Tack cure each surface with a visible light curing unit.



Remove excess cement while maintaining moderate pressure.



Light cure each margin for 20 sec. Alternatively, let the material self-cure for 4 min.



Finish and polish margins if necessary.

G-CEM LinkAce™ TECHNIQUE GUIDE

CEMENTATION TECHNIQUE for posts



Clean, rinse and thoroughly dry the post space using paper points.



Prepare the post according to the manufacturer's instructions.




Attach GC Automix Tip for Endo and apply extension tip. Extrude material into root canal and insert post immediately within 1 minute.


Maintain moderate pressure



Remove excess cement. In case of a cast post and core, tack cure each surface for 1 sec.



Light cure each surface / margin for 20 sec.



Let the material set for another 4 min.

STORAGE

Recommended for optimal performance, store at room temperature away from heat, moisture and direct sunlight (4-25°C) (39.2-77.0°F)



GC CORPORATION
TOKYO, JAPAN
© GC Corporation